

CSD-ES225 U U1U2 U3

LH EZ K

HR HC HE

HA V

SERVICE MANUAL

STEREO RADIO CASSETTE RECRDER

BASIC TAPE MECHANISM: TN-21ZSC-1685 BASIC CD MECHANISM: KSM-2131BDM

This Service Manual contains information about the difference between CSD-ES225.

If requiring the other information, see Service Manual of CSD-ES225 type <U,U1,U2,U3,LH> (S/M Code No.09-982-241-4FP), type <HR,EZ,K> (S/M Code No.09-983-248-8FP), type <HE,HC> (S/M Code No.09-986-273-1FP), type <V> (S/M Code No.09-987-287-5FP), and type <HA> (S/M Code No.09-98B-302-1FP).






Precaution to replace Optical block


Body or clothes electrostatic potential could ruin laser diode in the optical block. Be sure ground body and workbench, and use care the clothes do not touch the diode.

1) After the connection, remove solder shown in the right figure.

PICK-UP Assy P.C.B



CD MECHANISM EXPLODED VIEW 1/1



CD MECHANISM PARTS LIST 1/1

REF. NO	PART NO.	ANRI DES NO.	CRIPTION
2 6 7	9X-262-587-010 92-626-907-010 98-848-376-110 92-626-908-010 92-627-003-010	MOTOR CHASSI GEAR(A) OPTICAL PICK SHAFT SLED GEAR B	S ASSY UP KSS-213B RP
Δ	97-621-255-150	CCBEMTD3-3	


Α

G

Н

Κ





アイワ株式会社_{〒110-8710} 東京都台東区池之端1-2-11 **2**03 (3827) 3111 (代表) **AIWA CO.,LTD.**2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110-8710, JAPAN TEL:03 (3827) 3111 727105